

APX publishes programs in  
these categories:

Systems/Telecommunications

Home Management

Personal Development

Entertainment

Learning

# HICKORY DICKORY

## LEARNING

Teaches traditional and digital clock reading  
(ages 5-11)

**by Dale Disharoon**

Requires: ATARI BASIC Language Cartridge

Cassette version (1):  
(APX-10071)

ATARI 410 or 1010 Program Recorder  
16K RAM

Diskette version (1):  
(APX-20071)

ATARI 810 or 1050 Disk Drive  
24K RAM

Edition B

CONSUMER-WRITTEN PROGRAMS FOR

# ATARI®

H O M E C O M P U T E R S

# APX

ATARI Program Exchange

# **HICKORY DICKORY**

## **LEARNING**

Teaches traditional and digital clock reading  
(ages 5-11)

**by Dale Disharoon**

Requires: ATARI BASIC Language Cartridge

Cassette version (1):  
(APX-10071)

ATARI 410 or 1010 Program Recorder  
16K RAM

Diskette version (1):  
(APX-20071)

ATARI 810 or 1050 Disk Drive  
24K RAM

Edition B



# HICKORY DICKORY

by

Dale Disharoon

Program and Manual Contents©1981 Dale Disharoon

Copyright notice. Upon receipt of this computer program and associated documentation (the software), the author grants you a nonexclusive license to execute the enclosed software. This software is copyrighted. You are prohibited from reproducing, translating, or distributing this software in any unauthorized manner.

## Distributed By

The ATARI Program Exchange  
P.O. Box 3705  
Santa Clara, CA 95055

To request an APX Product Catalog, write to the address above, or call toll-free:

800/538-1862 (outside California)

800/672-1850 (within California)

Or call our Sales number, 408/727-5603

### Trademarks of Atari

ATARI is a registered trademark of Atari, Inc. The following are trademarks of Atari, Inc: 400, 410, 800, 810, 820, 822, 825, 830, 850, 1200XL.

**Limited Warranty on Media and Hardware Accessories.** Atari, Inc. ("Atari") warrants to the original consumer purchaser that the media on which APX Computer Programs are recorded and any hardware accessories sold by APX shall be free from defects in material or workmanship for a period of thirty (30) days from the date of purchase. If you discover such a defect within the 30-day period, call APX for a return authorization number, and then return the product to APX along with proof of purchase date. We will repair or replace the product at our option. If you ship an APX product for in-warranty service, we suggest you package it securely with the problem indicated in writing and insure it for value, as Atari assumes no liability for loss or damage incurred during shipment.

This warranty shall not apply if the APX product has been damaged by accident, unreasonable use, use with any non-ATARI products, unauthorized service, or by other causes unrelated to defective materials or workmanship.

Any applicable implied warranties, including warranties of merchantability and fitness for a particular purpose, are also limited to thirty (30) days from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded.

The provisions of the foregoing warranty are valid in the U.S. only. This warranty gives you specific legal rights and you may also have other rights which vary from state to state. Some states do not allow limitations on how long an implied warranty lasts, and/or do not allow the exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

**Disclaimer of Warranty on APX Computer Programs.** Most APX Computer Programs have been written by people not employed by Atari. The programs we select for APX offer something of value that we want to make available to ATARI Home Computer owners. In order to economically offer these programs to the widest number of people, APX Computer Programs are not rigorously tested by Atari and are sold on an "as is" basis without warranty of any kind. Any statements concerning the capabilities or utility of APX Computer Programs are not to be construed as express or implied warranties.

Atari shall have no liability or responsibility to the original consumer purchaser or any other person or entity with respect to any claim, loss, liability, or damage caused or alleged to be caused directly or indirectly by APX Computer Programs. This disclaimer includes, but is not limited to, any interruption of services, loss of business or anticipatory profits, and/or incidental or consequential damages resulting from the purchase, use, or operation of APX Computer Programs.

Some states do not allow the limitation or exclusion of implied warranties or of incidental or consequential damages, so the above limitations or exclusions concerning APX Computer Programs may not apply to you.

# Introduction

## OVERVIEW

Teachers in grades kindergarten through sixth have used HICKORY DICKORY to teach "telling time." A student or teacher selects one of six skill levels and the number of examples to work through. The skill levels let children of many ages and stages of development use HICKORY DICKORY. For each example, the program draws a standard clock face in finely-detailed graphics with the hour and minute hands set according to the chosen skill level. Students can enter the correct time either with a joystick controller or using the number keys on the computer keyboard. The program displays a hint following incorrect responses, and it moves on to a new example only after the student answers the current example correctly. The student's score displays after each example and at the end of the session.

## REQUIRED ACCESSORIES

ATARI BASIC Language Cartridge

Cassette version

16K RAM

ATARI 410 or 1050 Program Recorder

Diskette version

24K RAM

ATARI 810 or 1050 Disk Drive

## OPTIONAL ACCESSORIES

One ATARI Joystick Controller

## CONTACTING THE AUTHOR

Users wishing to contact the author about HICKORY DICKORY may write to him at:

Box 215  
Manchester, CA 95459

or call him at:

707/882-2477



## GETTING STARTED

### LOADING HICKORY DICKORY INTO COMPUTER MEMORY

1. If you plan to use the joystick controller, plug the joystick into the first controller jack of your computer console.
2. Insert the ATARI BASIC Language Cartridge in the slot of your computer.
3. If you have the cassette version of HICKORY DICKORY:
  - a. Turn on your TV set.
  - b. Turn on your computer and connect your program recorder to the computer and to a wall outlet.
  - c. Slide the HICKORY DICKORY cassette into the program recorder's cassette holder and press REWIND on the recorder until the tape rewinds completely. Then press PLAY.
  - d. Type CLOAD on your computer and then press the RETURN key two times. The tape will load into computer memory.
  - e. After the tape finishes loading, the word READY will display on your TV screen. Type RUN and press the RETURN key. The first display screen will appear on your TV screen.

If you have the diskette version of HICKORY DICKORY:

- a. Turn on your disk drive.
- b. When the BUSY light goes out, open the disk drive door and insert the HICKORY DICKORY diskette with the label in the lower right-hand corner nearest to you. Close the door.
- c. Turn on your computer and TV set.
- d. When the READY prompt displays on your TV screen, type RUN "D:HICKORY" and press the RETURN key. If you're using more than one disk drive, remember to follow the device initial (D) with the number of the drive containing the HICKORY DICKORY diskette (e.g., RUN "D2:HICKORY" for disk drive two). The program will load into computer memory and start.

**THE FIRST DISPLAY SCREEN**

After the program loads into computer memory, the screen fills with the word "CLOCK" and the "Hickory Dickory" tune plays.

## SELECTING YOUR OPTIONS

### Entering answers using the keyboard or a joystick

After the tune ends, choose whether to enter your answers using keys on the computer keyboard or using a joystick. Press the SELECT key until your choice flashes (KEYBOARD or JOYSTICK), and then press the START key. If you're using the joystick, hold it so that that red button is at your upper left, toward the TV screen.

### Choosing a skill level

After you press the START key, the skill level selection menu appears on your TV screen. The menu looks like this:

```
* MENU *  
  
1 - HOURS  
2 - HALF HOURS  
3 - 15 MINUTES  
4 - TEN MINUTES  
5 - FIVE MINUTES  
6 - MINUTES
```

Figure 1 Skill Level Menu

The selections are in order from easiest to most difficult:

Level 1- Examples are exact hours

Level 2- Examples are exact hours or half hours

Level 3- Examples are hours and all 15-minute intervals

Level 4- Examples are hours and all 10-minute intervals

Level 5- Examples are hours and all 5-minute intervals

Level 6- Examples are all possible minutes (00-59)

If you chose the keyboard option, then choose a skill level by pressing its number in the top row of the keyboard (pressing the RETURN key isn't necessary).

If you chose the joystick option, then choose a skill level by moving your joystick forward or backward until the flashing "X" is next to the skill level, and then press the red button.

#### Specifying the number of examples

The program then asks you how many examples you'd like to work through. You may do as few as two or as many as a hundred. For the keyboard version, enter your choice by typing the number and pressing the RETURN key. For the joystick version, push your joystick forward or backward until the number you want displays and then press the red trigger button.

# Using HICKORY DICKORY

## INTRODUCTION

For each example in HICKORY DICKORY, the program draws the minute marks and numbers of a clock face on your TV screen. It sets the hour and minute hands at random, but the setting is always within the skill level you chose. For example, if you chose level 1 (hours only), then all the examples will be exact hours. If you chose level 6, then the setting can be any hour and minute.

What happens next depends on whether you chose the joystick version or the keyboard version.

## USING THE JOYSTICK VERSION

The program displays the words

WHAT TIME IS IT?

at the bottom of the screen. You'll also see three zeros, with a colon between the first and second.

0:00

Pushing your joystick forward, toward the TV screen, moves the hour display (to the left of the colon) from 1 through 12. Pulling back, on the joystick, toward yourself, moves the hour display backwards from 12 to 1.

Set the hour and then push your joystick to the right to set the minutes. Change the minute (the two zeros to the right of the colon) in the same way you changed the hour. Move the minutes forward, from 00 through 59, by pushing the joystick forward. Move the backward, from 59 to 00, by pushing the joystick backward.

You may switch back and forth from minutes to hours by pushing your joystick to the left or the right.

When your "digital display" matches the time on the clock, press the red button. If your answer is right, the clock ticks, your score displays, and the program goes on to another example. If your answer is incorrect, the clock flashes and buzzes, a hint displays, and you try again. The program goes on to another example only after you answer one correctly.

You can stop the program whenever you want and return to the skill level menu by pressing the START key.

## USING THE KEYBOARD VERSION

The words:

THE TIME IS?

display at the bottom of the TV screen, beneath the clock. Decide what time you think the clock is showing and type in your answer. Use the number keys at the top of the computer keyboard. For each example, enter the hour, a colon, and the minutes. Be sure to type in the colon between the hours and the minutes. (Type a colon by pressing the SHIFT key and the "":"/;" key at the same time.) Always include the two zeros (00) for exact hours. For example, if the clock shows twelve o'clock, then enter your answer as:

12:00

If the minutes are less than 10, be sure to include the first zero between the colon and the minute. For example, if the clock shows six minutes past four o'clock, then enter your answer as:

4:06

Press the RETURN key each time you finish typing your answer. You can change your answer until you press the RETURN key. To change your answer, back up using the DELETE BACK S key in the top row of keys. Then type in your new answer.

If your answer is right, the clock ticks, your score displays, and the program goes on to another example. If your answer is incorrect, the clock flashes and buzzes, a hint displays, and you should try again. (Reminders. Be sure to enter the colon between the hour and minutes. Also, use the zero key at the top of the keyboard to enter a 0; don't use the capital letter "O".) The program goes on to another example only after you answer one correctly:

You can stop the program whenever you want and return to the skill level menu. Press the letter "Q" (for "quit") when you see the prompt "THE TIME IS?" and then press the RETURN key.

## SCOREBOARD

After you finish the number of examples you chose, the program displays your final score. For example, if you asked for 20 examples and answered 12 correctly and 8 incorrectly, then your score looks like this:

\* HICKORY DICKORY \*

YOU GOT 12 RIGHT  
OUT OF 20 PROBLEMS

PRESS (START/TRIGGER)

This display stays on the screen until you either press the START key (if you're playing the keyboard version) or the red button on your joystick (if you're playing the joystick version). The program then returns to the skill level menu. You may choose a level and the number of examples you want to work through next.



ATARI Program Exchange  
P.O. Box 3705  
Santa Clara, CA 95055

## Review Form

We're interested in your experiences with APX programs and documentation, both favorable and unfavorable. Many of our authors are eager to improve their programs if they know what you want. And, of course, we want to know about any bugs that slipped by us, so that the author can fix them. We also want to

know whether our instructions are meeting your needs. You are our best source for suggesting improvements! Please help us by taking a moment to fill in this review sheet. Fold the sheet in thirds and seal it so that the address on the bottom of the back becomes the envelope front. Thank you for helping us!

1. Name and APX number of program.

Hickory Dickory (071)

2. If you have problems using the program, please describe them here.

3. What do you especially like about this program?

4. What do you think the program's weaknesses are?

5. How can the catalog description be more accurate or comprehensive?

6. On a scale of 1 to 10, 1 being "poor" and 10 being "excellent", please rate the following aspects of this program:

- \_\_\_\_\_ Easy to use
- \_\_\_\_\_ User-oriented (e.g., menus, prompts, clear language)
- \_\_\_\_\_ Enjoyable
- \_\_\_\_\_ Self-instructive
- \_\_\_\_\_ Use (non-game programs)
- \_\_\_\_\_ Imaginative graphics and sound

7. Describe any technical errors you found in the user instructions (please give page numbers).

---

---

---

8. What did you especially like about the user instructions?

---

---

---

9. What revisions or additions would improve these instructions?

---

---

---

10. On a scale of 1 to 10, 1 representing "poor" and 10 representing "excellent", how would you rate the user instructions and why?

---

---

11. Other comments about the program or user instructions:

---

---


---

From

---

---

---



ATARI Program Exchange  
P.O. Box 3705  
Santa Clara, CA 95055

[seal here]